



# Tech Info Library

## DOS 3.3: BASIC entry vectors

Revised: 11/20/84  
Security: Everyone

DOS 3.3: BASIC entry vectors

=====

The following table shows the addresses of some machine language routines on a 48K Apple. Call them from your BASIC program after a command or DOS error if you wish.

Addr	Int	ASRom	ASRam	Description
\$9D56	36 E8	-	-	Chain entry
\$9D58	E5 24	FC 24	06 25	Run
\$9D5A	E3 E3	65 D8	67 10	Error entry
\$9D5C	00 E0	00 E0	84 1D	Initialize BASIC memory
\$9D5E	03 E0	3C D4	3C 0C	Continue after DOS commands
\$9D60	-	F2 D4	F2 0C	Line link resequence

Apple Tech Notes

Tech Info Library Article Number:570